



PharmaPrimer EMS

Description: This electric primer quickly and effortlessly removes excess air from your airless pump dispensers for a pharmaceutically elegant product. Suitable for use with a variety of airless pump dispensers including our MD Pump & MegaPump!

Features:

- Capable of priming a bottle in less than 5 seconds
- Reduce labor cost by drastically speeding up priming process
- Maintenance free

Instructions for Use:

- 1) Turn on
- 2) Remove over cap of airless pump and set aside so it can be replaced when priming is complete
- 3) Firmly push the bottom of airless pump into PharmaPrimer
- 4) Hold in place until piston has sufficiently risen to allow cream to reach actuator of pump

USA | Canada | Australia | International

medisca.com