



PRODUCT NO.: 7994



CHANGE PARTS, PROFILLER 3600 (Size 2)

DESCRIPTION: Change parts* for one capsule size include: Caps Tray / Body Sheet Set (A, B, C) / Spacer Plate / Orienter Tray / Capsule Locker

ADDITIONAL INFORMATION:

*Tamper may be required. Please provide your MEDISCA Sales Representative with the FB serial # (located on back of the Filler Base) and the capsule sizes currently being filled on your current capsule machine to ensure that all pieces are included for proper capsule filling.

Related Products:

- 7582: Tamper, 60 Pin, Size 2-3

Installing Change Parts:

No Tools Required

ProFiller 3600 system's patented design requires no tools or adjustments to change capsule size.

1. Lift out Orienter Tray.

2. Slide new Orienter Tray in place.

3. Unscrew 4 thumbscrews from corners of Filler Base.

4. Remove Body Sheet Set.

5. Switch Spacer Plate.

6. Position new size Body Sheet Set on Filler Base.

7. Secure with four thumb screws.

Please note that the information contained herein is for informational purposes only. The information is based on recognized compendia, manufacturers' instructions and/or other authoritative sources and texts. MEDISCA takes no responsibility for the validity or accuracy of this information. Customer MUST refer to USP, FDA, Health Canada, TGA and/or their State Board to ensure they comply with the specific regulations and ensure that appropriate procedures are in place.