



MEDISCA[®]
YOUR TRUSTED PARTNER IN COMPOUNDING

PRODUCT NO.: 9814



IMPULSE BAG HEAT SEALER (16" Seal Length)

6 mil Maximum Material Thickness

DESCRIPTION: This hand operated, table-top impulse heat sealer will easily seal poly bags up to 6 mil- (0.006") thick and 16" long. It has a solid state electronic timer for sealing bags of various thicknesses.

The heat sealer does not get hot when plugged in. The heating effect comes into action only when the upper jaw of the sealer comes into contact with the bag. This sealer is ideal for use with polyethylene, polypropylene, PVC, metalized or foil bags with poly laminated liners and many types of polyesters.

TECHNICAL SPECIFICATIONS:

Sealing L x W (in)	16 x 1/16
Shipping Weight (lb)	12
Impulse Power (W)	500
Maximum Sealing Thickness	6 mil

WARRANTY: 90 days